Magnetic Quick-Mount User Manual

The Magnetic Quick-Mount offers a fast, safe and efficient alternative to mounting your smoke alarm by drilling holes and screwing to the ceiling. Smoke alarms can now be mounted quickly and cleanly with this magnetic assembly system.

ASSEMBLING

1. **Attaching the Ceiling Disc**
   The ceiling disc (without magnets) must be mounted in the correct position as described in your smoke alarm's Instruction Manual. Remove the protective foil (a) and place the adhesive side against the ceiling. Apply light pressure (b) for at least 10 seconds. Please ensure it is mounted on a stable, dry surface free of dust and grease. Once assembled the magnet cannot be removed or repositioned.

2. **Attaching the Smoke Alarm Disc**
   The smoke alarm disc (with magnets) is mounted on the underside of the smoke alarm mounting plate. Remove the protective foil (a) and place the disc adhesive pad against the plate. Apply light pressure (c) for at least 10 seconds.

3. **Attaching the Smoke Alarm to the Ceiling**
   Firstly attach the mounting plate to the smoke alarm in the normal manner. The assembled smoke alarm is then simply placed against the ceiling disc (d).

(a)

(b)

(c)

(d)

Distributed in Australia & New Zealand by

newfield group

Newfield Group Ltd, New Zealand
www.newfield.co.nz